## 14) ASQ adjustments

14.1. Preset the radio as follows:

Channel

Volume Potentiometer middle;

- AM/FM

FM: **OFF** 

NB/ANL Squel ch

to OFF.

14.2. Preset the communication tester to:

- Receiver testing

- FM mode

27205kHz

- Frequency - FM modulátion 1. 2kHz

0FF - AM modulation

- Modulation generator at 1000Hz

- RF Level 1. 5uV

- Pre-emphasis 0FF

14.4. Adjust RP11, ASQ Threshold to a point, where squelch just open.



